

REPAIR SHEET

BRAND

RYOBI

DESCRIPTION


Grass Shear Caddy

MODEL NO.

ACSS02VNM

MFG. NO.

000996052




TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

12-6-21 (Rev:03)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	205735001	Handle Housing Assembly (Inc. Key No. 18)	1
2	205729001	Trigger Assembly	1
3	205737001	Housing Assembly	1
4	205739001	Upper Tube Assembly (Inc. Key No. 17)	1
5	660208049	Screw (M4 x 22 mm)	2
6	528191001	Wheel Shaft	2
7	528190001	Wheel	2
8	683069001	Trigger Spring	1
9	660208055	Screw (M4 x 12 mm)	2
10	523001001	Wire Pressure Plate	2

KEY NO.	PART NO.	DESCRIPTION	QTY.
11	205736001	Switch Assembly	1
12	661610009	Screw (M3.5 x 12 mm, T15 Torx Pan Hd.)	12
13	205738001	Lower Tube Assembly (Inc. Key No. 16)	1
14	678774012	Hex Nut (M8)	1
15	662104002	Screw (M8 x 36 mm)	1
16	941110081	QR Label	1
17	941588850	Data Label	1
18	940705490	RYOBI Logo Label	2
	Not Shown:		
	998000789	Operator's Manual	



ACSS02VNM

WIRING DIAGRAM

