


**TEK4® LITHIUM-ION
4 VOLT BATTERY PACK
Model No. AP4001 and AP4003
Repair Sheet**

RYOBI 4V BATTERY PACK – MODEL NO. AP4001 AND AP4003

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **BATTERY PACK** or when ordering replacement parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	130166003	Battery Pack (AP4001)		NOT SHOWN:			
	130166021	Battery Pack (AP4001)		988000312	Correlation Sheet	1	
	130166008	Battery Pack (AP4003)	1	987000706	Operator's Manual	1	
2	940976620	Data/Warning Label (AP4001)		10-21-13			
	940488211	Data/Warning Label (AP4001)		(REV:04)			
	940032138	Data/Warning Label (AP4003) ...	1				