


**RYOBI
GARAGE DOOR OPENER
MODEL NO. GD125
REPAIR SHEET**

ONE WORLD TECHNOLOGIES, INC.

1428 Pearman Dairy Road, Anderson, SC 29625 • Phone 1-877-205-5714
États-Unis, Téléphone 1-877-205-5714 • USA, Teléfono 1-877-205-5714

www.ryobitools.com

FIGURE A




RYOBI GARAGE DOOR OPENER – MODEL NO. GD125

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **GARAGE DOOR OPENER** or when ordering replacement parts.

PARTS LIST - FIGURE A

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	039857001002	Light Cover	1
2	039857001003	Bottom Shroud	1
3	039857001052	LED Board.....	1
4	039857001006	Bottom Plate	1
5	039841001029	Screw (M4 x 8 mm, Torx Pan Hd., Plastic)	4
6	039841001101	End Closed Connector	2
7	039841001099	18 AWG White Connection Wire.....	1
8	039841001100	18 AWG Black Connection Wire.....	1
9	039841001021	Nut (M5)	4
10	039857001054	Transformer	1
11	039841001031	Screw (M4 x 8 mm, Hex. Hd.).....	2
12	039857001009	18 Volt Motor	1
13	039857001051	Super Board.....	1
14	039857001065	Blue Connector & Wire Assembly.....	1
15	039857001062	Green Connector & Wire Assembly	1
16	039857001010	Screw (M4 x 16 mm, Pan Hd.).....	2
17	039857001058	Separation Piller.....	5
18	039841001208	Anti-Dust Cover	4
19	039841001059	Strain Relief.....	1
20	039857001004	Top Shroud	1
21	039841001026	Screw (M4 x 8 mm, Torx Pan Hd.)	4
22	039841001096	Power Cord	1
23	039857001070	WIFI Antenna	1
24	039841001022	Bolt (M6 x 16 mm).....	3
25	039841001024	Lock Washer (M6)	3
26	039841001023	Washer (M6)	3
27	039857001069	Main Body.....	1
28	039857001053	Safety Sensor	1
29	039841001033	Screw (M3 x 8 mm, Pan Hd.).....	4
30	039841001061	10 Amp Breaker	1
31	039857001059	Pillar	2
32	039841001067	GFCI Tower	1
33	039857001011	Screw (M3 x 25 mm, Pan Hd.).....	4
34	039857001063	Red Connector & Wire Assembly	1
35	039857001064	White Connector & Wire Assembly.....	1
36	039857001055	AC Socket.....	1
37	039857001057	18 AWG Black Connection Wire.....	1
38	039841001066	Separation Pillar.....	3
39	039841001189	Control Board	1
40	039857001001	Button	1

FIGURE B




RYOBI GARAGE DOOR OPENER – MODEL NO. GD125

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **GARAGE DOOR OPENER** or when ordering replacement parts.

PARTS LIST - FIGURE B

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	039841001303	7 ft. Rail Assembly.....	1	18	039841001179	Screw (M8 x 40 mm).....	4
2	039841001169	Cord Tag Assembly	1	19	039841001166	Wall Bracket.....	1
3	039841001187	Cord.....	1	20	039841001116	Tension Bracket.....	1
4	039841001178	U-Bracket	2	21	019687001701	Safety Sensor	2
5	039841001195	Nut (7/16 in.).....	10	22	019751001701	Indoor Keypad Console (GDA420)	1
6	039841001164	Hanging Bracket.....	2	23	019686001701	Car Remote	2
7	039841001161	Motor Sprocket.....	1	24	039841001203	37 cm Sleeve	3
8	039841001193	Bolt (7/16 in. x 3/4 in.).....	6	25	039841001202	100 cm Rail.....	3
9	039841001092	Straight Arm	1	26	039841001351	End Rail Assembly w/Belt and Pully	1
10	039841001196	Lock Nut (1/2 in.).....	2	27	039841001111	Screw (M4 x 10 mm).....	9
11	039841001090	Bent Arm.....	1	Not shown:			
12	039841001173	Axis Pin.....	1	039841001354	Main Hardware Kit		
13	039841001197	Screw.....	2	019687001103	GDA200 Assembly Hardware		
14	039841001165	Door Bracket	1	019688001701	GDA300 External Hardware		
15	039841001194	Bolt (1/2 in. x 1 in.).....	2	019688001010	GDA300 Assembly Hardware		
16	039841001142	Cotter Pin.....	2	995000220	Operator's Manual		
17	039841001170	Axis Pin (8 x 90 mm).....	1	995000221	Quick Start Guide		

RYOBI GARAGE DOOR OPENER – MODEL NO. GD125



RYOBI GARAGE DOOR OPENER – MODEL NO. GD125

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **GARAGE DOOR OPENER** or when ordering replacement parts.

PARTS LIST - FIGURE C

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	941001560	Not Intended for Permanent Wiring Label	1
2	941001272	Terminal Label	1
3	941001562	Entrapment Danger Label	1
4	941001558	Right Icon Label.....	1
5	941001557	Left Icon Label.....	1
6	941001559	Data Label.....	1
7	941120162	Entrapment Label (Wall of Garage) (English)	1
8	941120172	Entrapment Label (Wall of Garage) (French).....	1
9	941120173	Entrapment Label (Wall of Garage) (Spanish)	1
10	941001593	Cordwrap Label.....	1