


RYOBI
GARAGE DOOR OPENER
MODEL NO. GD200
REPAIR SHEET

RYOBI GARAGE DOOR OPENER – MODEL NO. GD200

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **GARAGE DOOR OPENER** or when ordering replacement parts.


FIGURE A



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	039841001070	Wifi Antenna.....	1
2	039841001007	Top Shroud	1
3	039841001008	Dust Cover	7
4	039841001004	Battery Cover.....	1
5	039841001037	Pin (2.5 x 20)	2
6	039841001001	Button Cover.....	1
7	039841001355	Belt and Pulley Assembly (Inc. Key No. 8).....	1
8	039841001111	Screw (M4 x 10 mm)	9
9	039841001030	Screw (M5 x 8 mm, Pan Hd.)	4

FIGURE B



RYOBI GARAGE DOOR OPENER – MODEL NO. GD200

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **GARAGE DOOR OPENER** or when ordering replacement parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	039841001166	Header Bracket.....	1
2	039841001164	Mounting Strap.....	2
3	039841001165	Door Bracket	1
4	039841001163	Curved Door Arm.....	1
5	039841001162	Straight Door Arm.....	1
6	039841001353	Emergency Release Rope Assembly (Inc. Key No. 25).	1
7	039841001178	Bracket	2
8	039841001352	Outer Trolley	1
9	039841001126	Sleeve	2
10	941120162	Entrapment Warning (English)	1
	941120172	Entrapment Warning (French).....	1
	941120173	Entrapment Warning (Spanish).....	1
11	039841001128	Rail.....	2
12	039841001301	GD200 Base Unit (Inc. Key Nos. 20-30)	1
13	039841001351	End Rail	1
14	019687001102	Sensor Bracket.....	2
15	019687001101	Safety Sensor (Set of 2).....	1
16	019688001701	Outdoor Keypad	1
17	019686001701	Car Remote	2
18	019696001701	Indoor Keypad	1
19	039841001116	Front Brace.....	1
20	941001273	Notice Label	1
21	941120170	Wiring Warning Label	1
22	941001272	Terminal Label.....	2
23	941488190	Data Label	1
24	941120168	Cord Wrap Label	1
25	941001271	Notice Emergency Label	1
26	941120161	Danger Entrapment Label (English).....	1
27	941120171	Danger Entrapment Label (French/Spanish).....	1
28	941001248	Instruction Label (English)	1
	941001250	Instruction Label (French).....	1
	941001251	Instruction Label (Spanish)	1
29	941120166	Left Icon Label.....	1
30	941120167	Right Icon Label.....	1

Not Shown:

039841001354	Main Hardware Kit
019687001103	Sensor Hardware (GDA200)
019696001010	Indoor Keypad Hardware (GDA400)
019688001010	Outdoor Keypad Hardware (GDA300)
039841001303	Rail Assembly (7 ft., GD200)
991000698	Operator's Manual
5-13-16	
(Rev:01)	