

REPAIR SHEET

BRAND

RYOBI

DESCRIPTION

MODEL NO.

P20104


P20104VNM

MFG. NO.

315286001

315286101

18 Volt Brushless Power Head




TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

11-22-21 (Rev:06)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.





P20104/P20104VNM


PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	315989001	Rear Handle Assembly (Inc. Key No. 2 & 13)	1
2	940705585	Logo Label	1
3	661864007	Screw (M4 x 18 mm, T15 Torx Pan Hd.)	15
4	660203052	Screw (M3 x 8 mm, Pan Hd.)	2
5	313244003	Motor & Gear Box Assembly	1
6	292194001	Motor Controller & Switch Assembly	1
7	315990001	Motor Volute Assembly	1
8	760649001	Variable Speed Switch	1
9	539255001	Hi-Lo Switch Cover	1
10	314833001	Switch Trigger Assembly	1
11	315386001	Boom Clamp Assembly	1
12	308991003	Front Handle Assembly (Inc. Key Nos. 14-15)	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
13	941588484	Data Label (P20104)	1
	941588902	Data Label (P20104VNM)	1
14	660643008	Screw (1/4-20 x 40 mm, Hex Hd.)	1
15	518949001	Wing Nut (1/4-20)	1
16	315991001	Boom Assembly (Inc. Key Nos. 18-20, P20104)	1
	316009001	Boom Assembly (Inc. Key Nos. 18-20, P20104VNM)	1
17	690140011	Compression Spring	1
18	941013005	Warning Label (French/Spanish)	1
19	941851150	Attachment Capable Label	1
20	941588795	Warning Icons Label	1
	Not Shown:		
	995000973	Operator's Manual	



P20104/P20104VNM



WIRING DIAGRAM