

REPAIR SHEET

BRAND

RYOBI

DESCRIPTION


18 Volt 6 Inch Pruning Saw

MODEL NO.

P25013VNM

MFG. NO.

106744001




TECHTRONIC INDUSTRIES POWER EQUIPMENT

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

4-14-23 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.






P25013VNM

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	205434002	Housing Assembly (Inc. Key Nos. 21-25 & 27-28)	1
2	545908001	Lock Off Button	1
3	699120001	Spring	1
4	545907001	Trigger	1
5	319101001	Output Shaft Assembly	1
6	319741002	Motor and Gear Box Assembly	1
7	205435002	Switch, Controller, and Battery Foot Assembly	1
8	615229002	Sprocket	1
9	635367003	Cap Washer	1
10	636159001	E-Ring	1
11	205422003	Hardware Pack for Guard	1
12	205422002	Front Guard Assembly (Inc. Key 11)	1
13	318908002	6 in. Saw Chain	1
14	318906002	6 in. Bar Guide	1
15	545915001	Scabbard	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
16	663208001	Screw (M4 x 5.5 mm)	1
17	319078001	Chain Tension Assembly	1
18	319086004	Sprocket Cover Assembly	1
19	660203087	Screw (M3 x 12 mm)	11
20	660208104	Screw (M4 x 30 mm, T15 Torx. Pan Hd.)	2
21	941110218	Data Label	1
22	941110219	Icon Warning Label	1
23	941110220	Warning Label	1
24	662364001	Screw (M4 x 8 mm, T15 Torx. Pan Hd.)	1
25	663198001	Screw (M6 x 26.7 mm)	1
26	679973004	Trigger Spring	1
27	941110221	QR Code Label	1
28	941110248	Logo Label	1
	Not Shown:		
	999000122	Operator's Manual	

**WIRING DIAGRAM**