

REPAIR SHEET

BRAND


RYOBI

DESCRIPTION

18 Volt Impact Wrench

MODEL NO.

P261




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

2-11-22 (Rev:04)


The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	203472001	Housing Assembly	1
2-CN	206312001	Motor Assembly	1
2-VN	206312004	Motor Assembly	1
3	528796001	Flat Slide Switch Button	1
4	760535002	3-Speed Switch	1
5	642098004	Rear Gear Case	1
6	662088001	Screw w/Washer (M4 x 11 mm, Rd. Hd.)	2
7	611574046	Ring Gear	1
8	692261003	Retaining Ring	1
9-CN	202677001	Gear Assembly	1
9-VN	203686002	Gear Assembly	1
10-CN	202678001	Cam Shaft Assembly	1
10-VN	203686003	Cam Shaft Assembly	1
11	512445001	Front Gear Washer	1
12	203556001	Front Gear Case Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
13	661943002	Screw (M6.5 x 25 mm, Pan Hd.)	4
14	280263010	LED Assembly	1
15	527836001	Forward/Reverse Button	1
16	203557001	Main Switch Assembly	1
17	660206042	Screw (M3.5 x 16 mm, Pan Hd.)	8
18	940114178	Logo Label	1
19-CN	941121364	Data Label	1
19-VN	941123627	Data Label	1
20	940230097	Warning Label	1
21	902578003	Sealing Plate	1
	Not Shown:		
	991000238	Operator's Manual (CN – 961152402) (VN – 961153116)	



WIRING DIAGRAM