

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

P322

DESCRIPTION

18 Volt Brad Nailer




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

8-11-22 (Rev:02)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	662461001	Screw (M3 x 16 mm)	1
2	541625002	Pressure Adjustment Knob	1
3	661923001	Screw (M4 x 15 mm)	4
4	634212002	Fix Washer	1
5-CN	204078004	Compress Cylinder (Inc. Key Nos. 45 & 46)	1
5-VN	204078007	Compress Cylinder (Inc. Key Nos. 45 & 46)	1
6	562961001	O-Ring	1
7	316586002	Valve Holder	1
8	565771001	O-Ring	1
9-CN	206151006	Piston and Rod Assembly	1
9-VN	206151009	Piston and Rod Assembly	1
10	541628001	Valve Shaft	1
11	562960001	O-Ring	1
12	315928001	Drive Cylinder and Magnet Assembly	1
13	562963001	Rubber Sleeve	1
14-CN	204604006	Driver Blade Assembly	1
14-VN	204604008	Driver Blade Assembly	1
15	564093001	Rubber Bumper	1
16-CN	204694005	Crank Case and Gear Assembly	1
16-VN	206252002	Crank Case and Gear Assembly	1
17	661749002	Screw w/Washer (M5 x 16 mm)	2
18-CN	206384004	Motor Assembly	1
18-VN	206384007	Motor Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
19-CN	204173003	Magazine Assembly (Inc. Key Nos. 47-49)	1
19-VN	204173007	Magazine Assembly (Inc. Key Nos. 47-49)	1
20	539473002	No-Mar Pad	2
21	658948002	Workpiece Contact	1
22	674106001	Pin	1
23-CN	204208009	Drive Guide Cover Assembly	1
23-VN	204208022	Drive Guide Cover Assembly	1
24-CN	204225003	Depth Adjustment Assembly	1
24-VN	204225005	Depth Adjustment Assembly	1
25	661853001	Screw (M4 x 4 mm)	1
26	660380008	Screw (M3 x 10 mm)	2
27	635100001	Shim Block	1
28	661902001	Screw (M2 x 14 mm)	2
29	634401001	Spring Plate	1
30	543909001	Mode Selector	1
31	543896001	LED Trigger	1
32	692784001	Spring	1
33	541623001	Trigger	1
34	693688001	Spring	1
35-CN	204696009	Housing Assembly (Inc. Key Nos. 40-44)	1
35-VN	204696016	Housing Assembly (Inc. Key Nos. 40-44)	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
36	660031017	Screw (M3.5 x 16 mm)	10
37-CN	204697011	Switch and Circuit Board Assembly	1
37-VN	204697015	Switch and Circuit Board Assembly	1
38	660180005	Screw (M5 x 32 mm)	1
39	670974003	Hex Nut (M5)	1
40	565798002	RYOBI Rear Logo	1
41	566052001	RYOBI Logo Badge	2
42	941120911	18 Gauge Callout Label (Non-Hero)	1
43	941120910	18 Gauge Callout Label (Hero)	1
44	941120909	Compatibility Label	1
45	941120908	AIRSTRIKE Logo Label	1
46	941120984	Second Cylinder Label	2
47-CN	941123886	Data Label	1
47-VN	941124145	Data Label	1
48	941120809	Flashing Light Label	1
49	941001791	18 Gauge Depot Label	1
	Not Shown:		
	998000681	Operator's Manual	

If a key number has multiple part numbers, please order the part that corresponds with the country of origin shown on the product's data label. CN = China VN = Vietnam

