


RYOBI
18 Volt Grease Gun
Model Number P3410
Repair Sheet

ONE WORLD TECHNOLOGIES, INC.
P.O. Box 1288, Anderson, SC 29622 • Phone 1-800-525-2579
www.ryobitools.com

RYOBI 18 VOLT GREASE GUN – MODEL NUMBER P3410




RYOBI 18 VOLT GREASE GUN – MODEL NUMBER P3410

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **18 VOLT GREASE GUN** or when ordering parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	660024015	Screw (M4 x 14 mm, T20 Torx Pan Hd.)	13	17	660160004	Set Screw (1/8 in. x 1/4 in., Hex Soc. Hd.)	1
2	564875001	Hose Holder (Front Cover)	1	18	662895001	Screw w/Washer (M4 x 8 mm, T20 Torx Pan Hd.)	2
3	660414015	Screw (M4 x 14 mm, T20 Torx Pan Hd.)	4	19	536323001	Lock Off Button.....	1
4	564876001	Hose Holder (Back Cover)	1	20	634714001	Spring Plate	1
5	204928002	Housing Assembly (Inc. Key Nos. 26-27)	1	21	536318001	Switch Trigger	1
6	204928003	Grease Tube & Cover Rod Plunger Assembly	1	22	695052001	Compression Spring	1
7	204928004	Gear Case Assembly	1	23	564900001	Hose Holder (Back Support).....	1
8	313739001	Vent Valve Kit	1	24	565005001	Hose Holder (Front Support).....	1
9	690366001	Ball (3/8 in. Dia.).....	1	25	536319001	Led Cover	1
10	690364001	Compression Spring	1	26	941655026	Logo Label	1
11	670081002	Washer	1	27	941122165	Data Label.....	1
12	697243001	Screw Plug.....	1			Not Shown:	
13	303534004	Hose Coupler	1		995000783	Operator's Manual (961153012)	
14	204928005	Circuit Board Assembly	1		4-4-19		
15	206928004	Motor Assembly	1		(Rev:01)		
16	313737001	Hose Assembly	1				

RYOBI 18 VOLT GREASE GUN – MODEL NUMBER P3410



WIRING DIAGRAM