

REPAIR SHEET

BRAND


RYOBI

DESCRIPTION

MODEL NO.

P344

18 Volt 3/8 in. Ratchet




ONE WORLD TECHNOLOGIES, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

3-19-21 (Rev:02)


The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	206570005	Ratchet Head Assembly	1
2	692911005	Compression Spring	1
3	698280001	Sleeve	1
4	658883001	Washer (ID13 x OD17 x 0.5t)	1
5	622587002	Crank Shaft	1
6	204375028	Gear Case Assembly	1
7	690268001	Steel Ball	2
8	673021003	Drive Pin	1
9	661487001	Screw (M3 x 10 mm, T10 Torx Pan Hd.)	4
10	204375029	Carrier and Gear Assembly	1
11	633795001	Washer (ID14 x OD25.5 x 0.5t)	1
12-CN	206570006	Motor and Switch Assembly	1
12-VN	206570010	Motor and Switch Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
13	204375030	Housing Assembly (Inc. Key Nos. 19-22)	1
14	565001003	Rubber Plug	2
15	539015001	Lock Out Switch	1
16	658792001	Switch Paddle	1
17	662328001	Screw (M3.5 x 12 mm, T10 Torx Pan Hd.)	7
18	673642001	3/8 in. Socket Bit	1
19	941120483	Battery Icon Label	1
20	941120484	Hot Surface Label	1
21-CN	941123024	Data Label	1
21-VN	941122360	Data Label	1
22	941655042	Logo Label	1
	Not Shown:		
	998000119	Operator's Manual	



WIRING DIAGRAM