

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

P4500

DESCRIPTION

18 Volt Telescoping Power Scrubber




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

3-15-22 (Rev:06)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.





P4500

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	941120549	Logo Label (Handle-Left)	1
2	941120548	Logo Label (Handle-Right)	1
3	315865003	Brush	1
4	940114179	Logo Label (Head)	2
5	663009003	Screw (M4 x 14 mm, T20 Torx Pan Hd.)	1
6-CN-A	537535001	Brush Adaptor	1
6-CN-B	537535002	Brush Adaptor	1
6-VN	537535002	Brush Adaptor	1
7	204676014	Handle and Clamp Assembly	1
8-CN	941122698	Data/Warning Label	1
8-VN	941123214	Data/Warning Label	1
9	541135001	Sleeve	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
10	360634001	Knob w/Pin	1
11	564912002	O-Ring	1
12	204676011	Battery Compartment Assembly	1
13	663007001	Screw (M3.5 x 14 mm, T15 Torx Pan Hd.)	10
14	204676013	Pivot Housing Assembly	1
15	537534001	Pivot Button	1
16	697738002	Pivot Button Spring	1
17	204676012	Handle Coupler Assembly (Inc. Key Nos. 1 & 2)	1
	Not Shown:		
	998000109	Operator's Manual (961153120)	

If a key number has multiple part numbers, please order the part that corresponds with the country of origin shown on the product's data label. CN = China VN = Vietnam

A / B — Replace key 6 based on your tool's serial number. Order key 6-A for tools BEFORE date code: CS2051; Order key 6-B for tools ON or AFTER date code: CS2051.