


**RYOBI
18 VOLT DUAL POWER
LED SPOTLIGHT
MODEL NO. P717
REPAIR SHEET**

ONE WORLD TECHNOLOGIES, INC.

1428 Pearman Dairy Road, Anderson, SC 29625 • Phone 1-800-525-2579

www.ryobitools.com

RYOBI SPOTLIGHT – MODEL NO. P717



RYOBI SPOTLIGHT – MODEL NO. P717

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **SPOTLIGHT** or when ordering replacement parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	019685001033	Icon Warning Label.....	1
2	019685001030	Ryobi Logo Label.....	2
3	019685001031	Data Label	1
4	019685001029	12V DC Cable	1
5	019685001032	Warning Label.....	1
Not Shown:			
	991000870	Operator's Manual	
	2-15-18		
	(Rev:01)		