

# REPAIR SHEET

BRAND


**RYOBI**

DESCRIPTION

MODEL NO.

**P7191**

## 18 Volt Beater Bar Head Assembly




**ONE WORLD TECHNOLOGIES, INC.**

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ [www.ryobitools.com](http://www.ryobitools.com)

2-25-21 (Rev:02)

*The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.*



**PARTS LIST**

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	662216001	Screw (M3 x 12 mm, T10 Torx Pan Hd.)	23
2	316447001	Brushroll Assembly	1
3	941123082	Data Label	1
4	316864001	Brushroll End Cap Assembly	1
5	903729001	Belt	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
6	538094001	Belt Side Cover	1
	<b>Not Shown:</b>		
	998000208	Operator's Manual (Models P724/P7191/P726, 961153244)	
	998000126	Operator's Manual (Models P7181/P726/P7191, 961153345)	