


**Ryobi 18V Compact Radio
Model No. P742
Repair Sheet**

RYOBI 18V COMPACT RADIO – MODEL NO. P742

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **RADIO** or when ordering replacement parts.



KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	019638001045	Battery Door Assembly	1
2	940114176	Logo Label	1
3	941121414	Data Label	1

Not Shown:
 991000122 Operator's Manual
 5-6-15
 (Rev:01)