

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PBLCS302

DESCRIPTION


ONE+ HP BL 7 1/4 IN. CIRC SAW



TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com


5.2.25 (Rev:01)



**PBLCS302****PARTS LIST**

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	206416004	Motor, PCBA, Upper Guard Assembly (Inc Key Nos. 2-3)	1
2	941119300	Blade Danger label	1
3	941119301	Behind Blade Warning Label	1
4	660165011	Screw, M4 TORX T-20 / L=12mm	8
5	696072001	Compression Spring	1
6	536252002	Switch Trigger	1
7	541596001	Safety Button	1
9	672552001	Safety Spring DIA 0.6MM	1
9	204416009	Housing Assembly (Inc Key Nos. 10-12)	1
10	941124621	Data Label	1
11	941119299	Icon Label	1
12	941119302	Clamp Warning Label	1
13	560219006	Hex Key Plug	1
14	680002006	Hex Key, #5 M6	1
15	661175006	Screw, M4X L58MM PH TORX T20 S	3
16	660024030	Screw, M4 X 16 mm	10
17	661268001	Screw, M3.5X8MM T15 TORX PAN HD.	2
18	558002002	Tension Spring Cover	1
19	691243001	Extension Spring, DIA0.023 \010104NN	1
20	204416010	Spindle Lock Assembly	1
21	558005002	Dust Adaptor	1
22	563468001	Dust Cover	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
23	561984001	Bumper	1
24	661245001	Screw, M6 X 20mm	1
25	206416005	Gear Box Assembly	1
26	660212047	Screw, M4X0.7 PH \L=14.5mm	1
27	543677001	Lower Guard Sleeve	1
28	558001001	Lower Guard	1
29	656366001	Washer, Flat OD40.2 X ID32.2 X T0.6 mm	1
30	657416002	Retaining Ring, ID29.6 X TI.5MM	1
31	687017001	Inner Blade Clamp	1
32	687111001	Outer Blade Clamp	1
33	660154010	Screw, M6X20MM	1
34	612031001	Depth Lock Nut, CH 1/4" -20UNC-2B	1
35	634295001	Bowed E-Ring	1
36	659497002	Depth Adjust Lever	1
37	204416011	Base Assembly	1
38	670974003	Insert Nut M5	1
39	660145008	Screw, M5X40MM T25 TORX	1
40	693616001	Carriage Bolt 1/4-20 X 5/8 IN	1
41	204416008	Rafter Hook Assembly	1
42	682142003	Blade	1
	Not Shown:		
	999000459	Manual	

**WIRING DIAGRAM**