

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PBLDD01

DESCRIPTION

18 Volt Brushless 1/2 in. Drill/Driver




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

1-12-22 (Rev:03)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.






PBLDD01

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	662288005	Screw (M8)	1
2	206089051	Chuck Assembly	1
3	660187012	Screw (M3 x 22 mm, T10 Torx Pan Hd.)	4
4	206089052	Gear Box Assembly	1
5	541650001	Forward/Reverse Button	1
6-CN	206089053	Motor and Circuit Board Assembly	1
6-VN	206089054	Motor and Circuit Board Assembly	1
7-CN	941123255	Data Label	1
7-VN	941123649	Data Label	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
8-CN	204089006	Housing Assembly (Inc. Key Nos, 7 & 10-11)	1
8-VN	204089008	Housing Assembly (Inc. Key Nos, 7 & 10-11)	1
9	204089007	High/Low Button	1
10	565689003	RYOBI Rubber Badge	1
11	565764001	Brushless Rubber Badge	1
12	662456001	Screw (M3 x 16 mm, T10 Torx Pan Hd.)	8
	Not Shown:		
	998000372	Operator's Manual	

**MOTOR AND
CIRCUIT BOARD
ASSEMBLY**



WIRING DIAGRAM