

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PBLRC25

DESCRIPTION

18 Volt 3/8 in. Extended Reach Ratchet




ONE WORLD TECHNOLOGIES, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

5-28-21 (Rev:01)


The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	206570014	Ratchet Head Assembly	1
2	692911005	Spring (1.3 mm)	1
3	698280004	Sleeve	1
4	690268001	Steel Ball (3.5 mm)	2
5	206570015	Gear Box, Motor, and Circuit Board Assembly	1
6	662675002	Screw (M4 x 8 mm)	4
7	660570005	Screw (M3 x 14 mm)	6
8	658792001	Switch Paddle	1
9	542997001	Lock-out Switch	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
10	204375035	Housing Assembly (Inc. Key Nos. 11-15)	1
11	565708004	BRUSHLESS Logo Badge	1
12	941123613	Data/Warning Label	1
13	941120788	Hot Surface Warning Label	1
14	565689001	RYOBI Logo Badge	1
15	941120665	Battery Statement Label	1
	Not Shown:		
	998000508	Operator's Manual	

**WIRING DIAGRAM**