

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PBLRT01

DESCRIPTION

18 Volt Brushless Rotary Tool




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

9-14-22 (Rev:02)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	699854001	Quick-Connect Coupler	1
2	204270003	Handpiece Assembly	1
3	545228001	Pen Holder	1
4	562961001	O-Ring	1
5-CN	206270005	Flex Shaft Assembly	1
5-VN	206270007	Flex Shaft Assembly	1
6-CN	206270006	Motor and Circuit Board Assembly	1
6-VN	206270008	Motor and Circuit Board Assembly	1
7	545482001	Fan Buffer	1
8	941120945	On/Off Label	1
9	566527001	Foot Pedal Plug Assembly	1
10	565101001	Rubber Pin	2
11	318709001	Hanger	1
12	660024018	Screw	6
13-CN	204270009	Housing Assembly (Inc. Key Nos. 17-21)	1
13-VN	204270010	Housing Assembly (Inc. Key Nos. 17-21)	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
14	204270006	Switch Assembly	1
15	204270007	Speed Dial Assembly	1
16	566467001	ONE+HP BRUSHLESS Badge	1
17	566052001	RYOBI Badge	1
18-CN	941123969	Data Label	1
18-VN	941124179	Data Label	1
19	918003534	Tag	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
20	941120944	Foot Pedal Label	1
21	941120943	Dial Graphics Label	1
	Not Shown:		
CN	318526001	40 Pc. Accessory Kit	1
VN	318526002	40 Pc. Accessory Kit	1
	998000739	Operator's Manual	

If a key number has multiple part numbers, please order the part that corresponds with the country of origin shown on the product's data label. CN = China VN = Vietnam

