

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PCL430

DESCRIPTION

18 Volt Oscillating Multi-Tool




ONE WORLD TECHNOLOGIES, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

3-27-23 (Rev:02)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.






PCL430

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	204232002	Housing Assembly (Inc. Key Nos. 3, 5, & 31)	1
2	662565001	Screw (M3 x 14 mm, T10 Torx Pan Hd.)	10
3	941123794	Data Label	1
4	680002015	Hex Key Wrench (#5, M6 x 60 mm x 28 mm)	1
5	941120867	Battery Label	1
6	566096001	Rubber Plug	2
7	565863001	Contact Plate Stopper	1
8	660024059	Screw (M4 x 13 mm, T20 Torx Pan Hd.)	6
9	204232003	Inner Housing Assembly	1
10	543413001	Switch Trigger	1
11	696791001	Compression Spring	1
12	206232002	Circuit Board Assembly	1
13	543414001	Motor End Cap	1
14	564725001	Motor Cushion	5
15	206232003	Motor Assembly	1
16	659954002	Motor Mount	1
17	662308001	Screw w/Washer (M3 x 5 mm, T10 Torx Pan Hd.)	2
18	681457016	Wood/Drywall Flush Cut Blade	1
19	562408002	Gear Cap	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
20	204232004	Spline Shaft Assembly	1
21	691171006	Needle Bearing	1
22	661379002	Screw (M6 x 18 mm, Hex Soc. Flat Hd.)	1
23	692512002	Sleeve	1
24	560324002	O-Ring	1
25	204232005	Output Shaft Assembly	1
26	680727009	Needle Bearing	1
27	566097001	Holder	2
28	660226017	Screw (M2 x 9 mm, T8 Torx Pan Hd.)	1
29	696792001	Compression Spring	1
30	543411001	Lock-On Button	1
31	941114320	Logo Label	1
32	681458028	Wood Cutting Blade	1
33	303590006	Detail Sanding Backing Pad	1
34	902424001	120 Grit Sanding Sheet	1
35	902460001	80 Grit Sanding Sheet	1
36	902423001	60 Grit Sanding Sheet	1
	Not Shown:		
	998000591	Operator's Manual	



WIRING DIAGRAM