

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PCL733

DESCRIPTION

ONE+™ 18 V WET/DRY VAC




ONE WORLD TECHNOLOGIES, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

8-11-23 (Rev:02)


The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	CN- 019182001049	Lid & Handle Assembly	1
	TH- 019182005049	Lid & Handle Assembly	1
2	CN- 019182001037	Crevice tool	1
	TH- 019182005037	Crevice tool	1
3	019182001015	Elbow Seal	2
4	CN- 019182001010	Elbow Connector	1
	TH- 019182005010	Elbow Connector	1
5	019182001022	Hose Assembly	1
6	019182001045	Washer (ID10 x OD3.2 x 10 mm)	3
7	019182001046	Screw (2.6M x 8 mm, Torx Pan. Hd)	3
8	CN- 019182001048	Motor, Circuit Board, Terminal & Fan Cover Assembly	1
	TH- 019182005048	Motor, Circuit Board, Terminal & Fan Cover Assembly	1
9	019182001028	Screw (M3 x 8 mm, Torx Pan. Hd.)	18
10	019182001016	Float Sealing	1
11	019182001013	Plastic Ball	1
12	CN- 019182001005	Bottom Housing	1
	TH- 019182005005	Bottom Housing	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
13	019182001020	Filter Seal	1
14	019182001018	Tank Seal	2
15	CN- 019182001012	Plastic Ball Cage	1
	TH- 019182005012	Plastic Ball Cage	1
16	312711005	Filter w/Label	1
17	CN- 019182001047	Tank and Latch Assembly	1
	TH- 019182005047	Tank and Latch Assembly	1
18	CN- 019182001008	Hose Clip	2
	TH- 019182005008	Hose Clip	2
19	019182001027	Screw (3M x 8 mm) w/ Washer	2
20	918003537	Hang Tag	1
21	CN- 01918200101K	Data Label	1
	TH- 01918200501K	Data Label	1
22	01918200103K	Battery Label	1
23	01918200102K	Icon Warning Label	1
	Not Shown:		
	999000106	Operator's Manual	



WIRING DIAGRAM — CN