

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PSBHM01

DESCRIPTION

18 Volt 1/2 in. Hammer Drill




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

2-14-22 (Rev:02)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.





PSBHM01

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	660134006	Chuck Screw (M6)	1
2	670794024	Chuck	1
3	660570005	Screw (M3 x 14 mm)	13
4	206613019	Gear Train Assembly	1
5	204584008	High/Low Button	1
6	206613011	Motor Stator, and Circuit Board Assembly	1
7	206613012	Motor Rotor and Pinion Assembly	1
8	204584007	Housing Assembly (Inc. Key Nos. 10-13)	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
9	541215001	Forward/Reverse Button	1
10	565689001	RYOBI Logo Badge	1
11	565708001	Brushless Logo Badge	1
12	941123243	Data Label	1
13	941120665	Battery Statement Label	1
	Not Shown:		
	998000351	Operator's Manual (961153452)	

