

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PSBRC26

DESCRIPTION

18 Volt 3/8 in. Ratchet




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

5-18-23 (Rev:02)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.


RYOBI PSBRC26



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1-CN	206570023	Ratchet Head Assembly	1
1-VN	206570026	Ratchet Head Assembly	1
2	692911005	Compression Spring	1
3	698280004	Sleeve	1
4	622587004	Crank Shaft	1
5	690268001	Steel Ball	2
6-CN	206570024	Motor, Switch and Control Board Assembly	1
6-VN	206570027	Motor, Switch and Control Board Assembly	1
7-CN	662675004	Screw (M4 x 8 mm, T15 Torx Pan Hd.)	4
7-VN	662675002	Screw (M4 x 8 mm, T15 Torx Pan Hd.)	4
8	660570005	Screw (M3 x 14 mm, T10 Torx Pan Hd.)	6
9	658792001	Paddle Switch	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
10	542997001	Lock Out Switch	1
11-CN	204375040	Housing Assembly (Inc. Key Nos. 12-16)	1
11-VN	204375042	Housing Assembly (Inc. Key Nos. 12-16)	1
12	565708004	Brushless Label	1
13	565689001	Logo Label	1
14	941120788	Hot Surface Label	1
15-CN	941124233	Data Label	1
15-VN	941124237	Data Label	1
16	941119062	Battery Icon Label	1
	Not Shown:		
	999000089	Operator's Manual	



WIRING DIAGRAM