



**TEK4® LED
4 VOLT FLASHLIGHT
Model No. RP4400
Replacement Parts List**

TECHTRONIC INDUSTRIES NORTH AMERICA, INC.


1428 Pearman Dairy Road, Anderson, SC 29625

Phone 1-800-860-4050

www.ryobitools.com

RYOBI LED FLASHLIGHT – MODEL NO. RP4400

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **FLASHLIGHT** or when ordering replacement parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	83-187-R00H000	Data Label	1	NOT SHOWN:			
2	130166003	Battery Pack.....	1	987000655		Operator's Manual.....	1
3	52-187-R04R000	Battery Cap	1				
4	140129002	Charger.....	1	6-19-09			
				(REV:00)			