


## REPAIR SHEET

|           |        |                             |
|-----------|--------|-----------------------------|
| BRAND     | RYOBI  | DESCRIPTION                 |
| MODEL NO. |        |                             |
|           | RP4510 | Tek4® ALLPLAY™ Music Player |




**ONE WORLD TECHNOLOGIES, INC.**

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ [www.ryobitools.com](http://www.ryobitools.com)

2-23-21 (Rev:03)

*The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.*



## PARTS LIST

| KEY NO. | PART NO.     | DESCRIPTION                       | QTY. |
|---------|--------------|-----------------------------------|------|
| 1       | 019606001020 | Battery Cap Assembly              | 1    |
| 2       | 019606001016 | Belt Clip                         | 1    |
| 3       | 019606001025 | Armband                           | 1    |
| 4       | 019606001024 | Earbuds                           | 1    |
| 5       | 019606001023 | USB Cable                         | 1    |
| 6       | 019606001026 | Logo Label                        | 1    |
| 7       | 019606001027 | Data Label                        | 1    |
| 8       | 130166003    | Battery Pack (4 V Li-Ion, AP4001) | 1    |

| KEY NO. | PART NO.          | DESCRIPTION                               | QTY. |
|---------|-------------------|-------------------------------------------|------|
| 9       | 140132009         | 4 V Charger                               | 1    |
| 10      | 019606001017      | E-Ring                                    | 1    |
| 11      | 019606001018      | Torsion Spring                            | 1    |
| 12      | 019606001019      | T-Pin                                     | 1    |
|         | <b>Not Shown:</b> |                                           |      |
|         | 987000706         | Operator's Manual (AP4001) (019606001035) | 1    |
|         | 987000654         | Operator's Manual (AP4700) (019606001034) | 1    |
|         | 987000822         | Operator's Manual (RP4510) (019606001033) | 1    |