


REPAIR SHEET

BRAND RYOBI		DESCRIPTION EXPAND-IT Straight Shaft Trimmer Attachment
MODEL NO. RY15527 RY15527VNM	MFG. NO. 311247006 311247106	



TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

7-5-22 (Rev:08)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	941588552	Max. Run Time/Performance Label	1
2	315992001	Straight Shaft Assembly (Inc. Key Nos. 3-5, RY15527)	1
	316008001	Straight Shaft Assembly (Inc. Key Nos. 3-5, RY15527VNM)	1
3	940749034	Lower Boom Icon Label	1
4	941851149	Ryobi Expand-it Label	1
5	941588488	Data Label (RY15527)	1
	941588903	Data Label (RY15527VNM)	1
6	660738002	Screw (1/4-20 x 1-1/4 in., Hex Washer Hd.)	1
7	679958001	Compression Spring	1
8	313285005	Grass Deflector Assembly (Inc. Key Nos. 1, 6-7, & 9-10)	1
9	638016003	Line Cut-off Blade	1
10	662148001	Screw (M4.5 mm x 1 mm, Pan Hd.)	2
11	660642001	Screw (1/4-20 x 1-1/4 in., Hex Washer Hd.)	1
12	660641001	Screw (10-24 x 5/8 in., Hex Washer Hd.)	1
13	678011001	Flanged Washer	1
14	308210009	Gear Head	1
15	314608005	Bump Feed Trimmer Head Assembly (Inc. Key No. 7)	1
16	638125001	Grass Deflector Clamp	1
17	532048003	Crank Handle	1
	Not Shown:		
	995000976	Operator's Manual	

