


REPAIR SHEET

BRAND		DESCRIPTION
RYOBI		
MODEL NO.	MFG. NO.	
RY40402	107966001	40 Volt Blower
RY40402VN	107966014	
RY40402VNM	107966101	




TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

3-15-22 (Rev:08)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.





RY40402/RV40402VN/RV40402VNM

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	661817001	Screw (M4 x 14 mm, T15 Torx Pan Hd.)	16
2	311220001	Handle Assembly (Inc. Key No. 6)	1
3	525552001	Switch Trigger	1
4	940999144	Icon Warning Label	1
5	940979005	Data Label (RY40402)	1
	941588338	Data Label (RY40402VN)	1
	941588592	Data Label (RY40402VNM)	1
6	940705207	Logo Label (Left/Right)	2
7	270504001	Switch Assembly	1
8	679973002	Trigger Spring	1
9	526489001	Inlet Housing Cover	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
10	205369001	Inlet Housing Assembly (Inc. Key No. 5, RY40402)	1
	205159002	Inlet Housing Assembly (Inc. Key No. 5, RY40402VNM)	1
11	526058001	Fan	1
12	660502002	Screw (M5 x 11 mm, Pan Hd.)	4
13	741956002	Motor	1
14	311221001	Housing Assembly	1
15	526055001	Blower Housing Outlet (Inc. Key No. 4)	1
16	526063001	Blower Tube	1
	Not Shown:		
	990000700	Operator's Manual	