
RY802900/RY802900VNM/RY802900AND QUICK REFERENCE GUIDE


WARNING:

This Quick Reference Guide is not a substitute for reading the operator's manual. To reduce the risk of injury or death, user must read and understand operator's manual before using this product. All page references refer to the operator's manual.

FIRST TIME ASSEMBLY




Connect the spray wand to the trigger handle (see




Connect the high pressure hose to the trigger handle (see page 7).

Connect the high pressure hose to the pump



Completely uncoil and straighten high pressure hose to prevent kinks.

Connect your garden hose to the pressure washer



Completely uncoil garden hose or remove completely from reel to prevent kinks.



Turn water faucet on fully.




Make sure there are no leaks.



With no nozzle installed, squeeze the trigger to relieve air pressure. Hold the trigger until a steady stream of water appears.

Pour all but 2 oz. of the provided lubricant into the engine through the oil fill hole. Check and add additional lubricant as needed until the level reaches the upper portion of the hatched area on the dipstick. Do not overfill. (See page 9)



Turn the fuel valve to OFF before adding lubri-




Set unit on flat surface so engine is level. Remove dipstick, wipe clean, put back in hole (but don't screw in) and check lubricant level.

DO NOT OVERTILT THE UNIT!










STARTING THE UNIT (COLD START)

Add fuel (see page 10).

NOTICE:




Do not use E15 or E85 fuel in this product. It is a violation of federal law and will damage the unit and void your warranty. Only use unleaded gasoline containing up to 10% ethanol.




This is a 4-cycle engine. Do not mix fuel and lubricant together.




Mix fuel stabilizer with gasoline according to manufacturer's directions prior to filling the




Move the choke lever to the CHOKE position (see






Allow engine to run for several seconds, then move choke to RUN position (see page 10).



RESTARTING THE UNIT (HOT RESTART)

Pull starter grip and rope to start (see page 10).





- check for enough fuel;
- may need to adjust choke position;
- try starting again.


There may be residual water in the pump and/or lubricant in the engine due to performance testing.

USING DETERGENT

Place soap injection hose in Install nozzle and rotate the detergent container (see selector to blue 💖 or blue setting (see page 12).










page 12).

Use of the soap nozzle will activate soap injector at a 20:1 dilution ratio. WARNING! Never use bleach or solvent-based detergent.

- Will damage your pump
- Will void your warranty
- Will damage plants/shrubs

NOZZLE SELECTION GUIDE

Use the chart below to determine the correct nozzle for your job.



BEFORE STORING THE UNIT

Always add Pump Protector to the unit after each use and before storing. This will significantly improve pump life. (See page 13)

Pump Protector is available from your local retailer. For further assistance, call customer service

To add, follow the instructions provided by the Pump Protector manufacturer.



Make the most of your purchase! Go to www.ryobitools.com and register your new tool online. For questions about operating or maintaining your product, please call, 1-800-860-4050.