


## REPLACEMENT PARTS LIST

|                                 |                              |                                                |
|---------------------------------|------------------------------|------------------------------------------------|
| BRAND<br><b>RYOBI</b>           |                              | DESCRIPTION<br><b>42 in. Riding Lawn Mower</b> |
| MODEL NO.<br><b>RYRM8002CAN</b> | MFG. NO.<br><b>099270015</b> |                                                |



### TECHTRONIC INDUSTRIES POWER EQUIPMENT

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ [www.ryobitools.com](http://www.ryobitools.com)

999000169  
7-17-23 (REV:02)

*The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.*





# RYRM8002CAN

## PARTS LIST — FIGURE A

| KEY NO. | PART NO.          | DESCRIPTION                                  | QTY. |
|---------|-------------------|----------------------------------------------|------|
| 1       | 997000169         | Front Wheel Assembly                         | 2    |
| 2       | 997000179         | Rear Wheel Assembly                          | 2    |
| 3       | 996987001         | Wheel Hub                                    | 2    |
| 4       | 997134001         | Lock Spring Washer (ID20.6 x OD30.6 x 4.8T)  | 2    |
| 5       | 997138001         | Castle Nut (M20)                             | 2    |
| 6       | 997139001         | Cotter Pin                                   | 2    |
| 7       | 997143001         | Acorn Nut (M14)                              | 8    |
| 8       | 996029001         | Wheel Hub Cover                              | 2    |
| 9       | 996988001         | Key (6 mm x 6 mm x 30 mm)                    | 2    |
| 10      | 994842001         | Washer (ID20.5 x OD28 x 4T)                  | 4    |
| 11      | 996997001         | Wheel Spacer                                 | 4    |
| 12      | 994857001         | Bearing Cover                                | 4    |
| 13      | 996998001         | Flange Bolt (M12 x 170 mm, Hex Hd.)          | 2    |
| 14      | 996999001         | Flange Nut (M12)                             | 2    |
| 15      | 996990001         | Caster Fork                                  | 2    |
| 16      | 996991001         | Bearing Assembly Base                        | 2    |
| 17      | 997125001         | Rubber Seal                                  | 2    |
| 18      | 996992001         | Tapered Roller Bearing (ID 25 mm x OD 52 mm) | 4    |
| 19      | 996993001         | Bearing Assembly Spacer                      | 2    |
| 20      | 997036001         | Fender Washer (ID12.5 x OD40 x 2t)           | 2    |
| 21      | 996994001         | Bearing Assembly Cap                         | 2    |
| 22      | 996995001         | Fender Washer (ID8.4 x OD37 x 6t)            | 2    |
| 23      | 994770001         | Lock Washer (M8)                             | 2    |
| 24      | 996046001         | Bolt (M8 x 25 mm)                            | 2    |
| 25      | 997130001         | Caster Fork Cover                            | 2    |
|         | <b>Not Shown:</b> |                                              |      |
|         | 998000937         | Operator's Manual                            |      |


## FIGURE A — WHEELS AND HUB CAPS





**PARTS LIST — FIGURE B**

| KEY NO. | PART NO.  | DESCRIPTION                    | QTY. |
|---------|-----------|--------------------------------|------|
| 1       | 997931001 | Floor Board                    | 1    |
| 2       | 994989001 | Screw (M6 x 16 mm, Torx Hd.)   | 19   |
| 3       | 997930001 | Foot Rest                      | 1    |
| 4       | 997927001 | Front Fascia                   | 1    |
| 5       | 997929001 | LED Headlight Assembly (Right) | 1    |
| 6       | 997928001 | LED Headlight Assembly (Left)  | 1    |
| 7       | 997000185 | Fascia Brace (Right)           | 1    |
| 8       | 997000184 | Fascia Brace (Left)            | 1    |
| 9       | 994785001 | Clip-On Nut (M6)               | 4    |
| 10      | 997094001 | Screw (M3.5 x 13 mm, Pan Hd.)  | 12   |



PARTS LIST — FIGURE C

| KEY NO. | PART NO.  | DESCRIPTION                  | QTY. |
|---------|-----------|------------------------------|------|
| 1       | 997919001 | Joystick Assembly            | 1    |
| 2       | 994000001 | Joystick Bellow Assembly     | 1    |
| 3       | 997000029 | Upper Joystick Handle        | 1    |
| 4       | 997000165 | Set Screw (M6 x 5 mm)        | 2    |
| 5       | 997000036 | Joystick Damper              | 2    |
| 6       | 997000035 | Damper Bushing               | 4    |
| 7       | 994867001 | Flange Nut (M8)              | 4    |
| 8       | 994771001 | Washer (ID8.4 x OD16 x 1.6t) | 4    |
| 9       | 994770001 | Spring Washer (M8)           | 4    |
| 10      | 997000161 | Screw (M8 x 30 mm, Hex Hd.)  | 4    |






# RYRM8002CAN

## PARTS LIST — FIGURE D

| KEY NO. | PART NO.  | DESCRIPTION                       | QTY. |
|---------|-----------|-----------------------------------|------|
| 1       | 997000174 | 42 in. Deck                       | 1    |
| 2       | 997932001 | Motor Cover                       | 2    |
| 3       | 997933001 | Deck Motor                        | 2    |
| 4       | 996251001 | Lock Nut (M6 x 1.00, Flange Hd.)  | 16   |
| 5       | 997000232 | Stud (M6)                         | 2    |
| 6       | 996034001 | Washer (M6)                       | 1    |
| 7       | 996039001 | Mounting Shaft                    | 1    |
| 8       | 996250001 | Screw (M6 x 40 mm)                | 1    |
| 9       | 996057001 | Bolt (M6 x 25 mm, Flange Hex Hd.) | 4    |
| 10      | 997000175 | Deck Bracket                      | 1    |
| 11      | 996050001 | Carriage Bolt (M8 x 20 mm)        | 2    |
| 12      | 994867001 | Flange Nut (M8)                   | 2    |


| KEY NO. | PART NO.  | DESCRIPTION                    | QTY. |
|---------|-----------|--------------------------------|------|
| 13      | 996205001 | Shoulder Bolt (M10 x 70 mm)    | 2    |
| 14      | 996355001 | Spring Washer (M10)            | 2    |
| 15      | 996265001 | Front Deck Roller Wheel        | 2    |
| 16      | 996192001 | Flange Lock Nut (M10)          | 2    |
| 17      | 997074001 | Baffle                         | 1    |
| 18      | 994791001 | Carriage Bolt (M6 x 16 mm)     | 3    |
| 19      | 997920001 | Crosscut Blade Adapter         | 2    |
| 20      | 682533001 | Crosscut Top Blade (21 in.)    | 2    |
| 21      | 682282001 | Crosscut Bottom Blade (21 in.) | 2    |
| 22      | 997028001 | Blade Retainer Washer          | 2    |
| 23      | 996261001 | Flange Lock Nut (M10)          | 2    |



**PARTS LIST — FIGURE E**

| KEY NO. | PART NO.  | DESCRIPTION                             | QTY. |
|---------|-----------|-----------------------------------------|------|
| 1       | 997953001 | Side Discharge Chute Assembly           | 1    |
| 2       | 997974001 | Discharge Chute Hinge                   | 1    |
| 3       | 994980001 | Discharge Chute Spring                  | 1    |
| 4       | 996292001 | Push-On Retainer Clip                   | 1    |
| 5       | 997085001 | Mulch Plug Assembly (Inc. Key Nos. 6-9) | 1    |
| 6       | 996203001 | Rubber Strap                            | 2    |


| KEY NO. | PART NO.  | DESCRIPTION        | QTY. |
|---------|-----------|--------------------|------|
| 7       | 996212001 | Bungie Anchor      | 2    |
| 8       | 996213001 | Screw (M5 x 16 mm) | 2    |
| 9       | 996211001 | Latch Spring       | 2    |
| 10      | 997000229 | Screw (M4 x 15 mm) | 2    |
| 11      | 996301001 | Lock Nut (M4)      | 2    |



**PARTS LIST — FIGURE F**

| KEY NO. | PART NO.  | DESCRIPTION                                 | QTY. |
|---------|-----------|---------------------------------------------|------|
| 1       | 997158001 | Gearbox Assembly (Left)                     | 1    |
| 2       | 997159001 | Gearbox Assembly (Right)                    | 1    |
| 3       | 997000001 | Tie Rod                                     | 3    |
| 4       | 996323001 | Bolt (M10 x 45 mm, Hex Hd.)                 | 6    |
| 5       | 994998001 | Lock Spring Washer (ID10.9 x OD16.1 x 2.6T) | 6    |

| KEY NO. | PART NO.  | DESCRIPTION                        | QTY. |
|---------|-----------|------------------------------------|------|
| 6       | 997088001 | Flange Bolt (M8 x 110 mm, Hex Hd.) | 4    |
| 7       | 994996001 | Washer (M10)                       | 6    |
| 8       | 997000227 | 80V Drive Motor                    | 2    |
| 9       | 997000231 | Screw (M8 x 30 mm, Soc. Hd.)       | 8    |
| 10      | 994867001 | Flange Nut (M8)                    | 4    |






# RYRM8002CAN

## PARTS LIST — FIGURE G

| KEY NO. | PART NO.  | DESCRIPTION                          | QTY. |
|---------|-----------|--------------------------------------|------|
| 1       | 997016001 | Deck Lift Linkage and Axle Assembly  | 1    |
| 2       | 997025001 | Deck Lift Spring                     | 2    |
| 3       | 997014001 | Deck Lift Axle Bushing Top           | 2    |
| 4       | 997015001 | Deck Lift Axle Bushing Bottom        | 2    |
| 5       | 997013001 | Deck Lift Axle Mount                 | 2    |
| 6       | 994996001 | Washer (M10)                         | 10   |
| 7       | 994998001 | Lock Washer (ID10.9 x OD16.1 x 2.6t) | 4    |
| 8       | 997106001 | Bolt (M10 x 30 mm)                   | 4    |
| 9       | 996233001 | Cotter Pin                           | 5    |
| 10      | 996263001 | Nut (M10)                            | 8    |
| 11      | 997126001 | Hanger Stud                          | 2    |
| 12      | 997017001 | J-Hook Deck Hanger                   | 2    |
| 13      | 997000171 | J-Hook Bushing                       | 2    |
| 14      | 997018001 | Deck Lift Linkage                    | 2    |
| 15      | 997093001 | Deck Lift Linkage Spacer             | 2    |
| 16      | 997019001 | Deck Lift Linkage Bushing            | 2    |

| KEY NO. | PART NO.  | DESCRIPTION                    | QTY. |
|---------|-----------|--------------------------------|------|
| 17      | 994763001 | Washer (ID17 x OD30 x 3t)      | 2    |
| 18      | 994891001 | Washer (M13)                   | 4    |
| 19      | 994892001 | Cotter Pin (12 mm)             | 1    |
| 20      | 997023001 | Deck Lift Lever Torsion Spring | 1    |
| 21      | 997022001 | Deck Lift Lever                | 1    |
| 22      | 994972001 | Deck Lift Handle               | 1    |
| 23      | 997679001 | Detent Plate                   | 1    |
| 24      | 994771001 | Washer (ID8.4 x OD16 x 1.6t)   | 3    |
| 25      | 994770001 | Lock Washer (M8)               | 3    |
| 26      | 996046001 | Bolt (M8 x 25 mm)              | 3    |
| 27      | 997128001 | Cut Height Memory Plug         | 1    |
| 28      | 997140001 | Hinge Cotter Pin               | 1    |
| 29      | 997000170 | Front Deck Hook                | 1    |
| 30      | 997097001 | Front Deck Hanger Pivot Axle   | 1    |
| 31      | 996999001 | Flange Nut (M12)               | 1    |
| 32      | 994833001 | E-Clip (12 mm)                 | 2    |






# RYRM8002CAN

## PARTS LIST — FIGURE H

| KEY NO. | PART NO.  | DESCRIPTION                  | QTY. |
|---------|-----------|------------------------------|------|
| 1       | 997012001 | Brake Cable                  | 2    |
| 2       | 997011001 | Brake Pedal Spring           | 1    |
| 3       | 994837001 | Brake Switch                 | 1    |
| 4       | 996013001 | Lock Pin (8 mm)              | 3    |
| 5       | 994771001 | Washer (ID8.4 x OD16 x 1.6t) | 5    |
| 6       | 994929001 | Clevis Pin (M16 x 70 mm)     | 1    |
| 7       | 994928001 | Brake Pedal Bushing          | 2    |
| 8       | 997004001 | Brake Pedal Lever            | 1    |
| 9       | 994930001 | Lock Pin (16 mm)             | 1    |
| 10      | 997009001 | Brake Pedal Rubber Pad       | 1    |


| KEY NO. | PART NO.  | DESCRIPTION                  | QTY. |
|---------|-----------|------------------------------|------|
| 11      | 997008001 | Parking Brake Torsion Spring | 1    |
| 12      | 997005001 | Parking Brake Pedal          | 1    |
| 13      | 997010001 | Parking Brake Rubber Pad     | 1    |
| 14      | 997006001 | Parking Brake Latch          | 1    |
| 15      | 997007001 | Clevis Pin (M8 x 60 mm)      | 1    |
| 16      | 997089001 | Bolt (M8 x 70 mm, Hex Hd.)   | 2    |
| 17      | 994770001 | Lock Washer (M8)             | 2    |
| 18      | 997003001 | Brake Latch Hook             | 1    |
| 19      | 996346001 | Hex Nut (M8)                 | 1    |
| 20      | 997131001 | Bolt (M8 x 40 mm, Hex Hd.)   | 1    |



**PARTS LIST — FIGURE I**

| KEY NO. | PART NO.  | DESCRIPTION         | QTY. |
|---------|-----------|---------------------|------|
| 1       | 997000167 | Control Panel Plate | 1    |
| 2       | 994963001 | USB-C Module        | 1    |
| 3       | 997792001 | Key Module          | 1    |
| 4       | 997966001 | Key                 | 1    |
| 5       | 997082001 | PTO Gasket          | 1    |

| KEY NO. | PART NO.  | DESCRIPTION                 | QTY. |
|---------|-----------|-----------------------------|------|
| 6       | 997345001 | PTO                         | 1    |
| 7       | 996361001 | Spring Washer               | 1    |
| 8       | 997923001 | Accessory Button            | 1    |
| 9       | 994989001 | Screw (M6 x 16mm, Torx Hd.) | 4    |






# RYRM8002CAN

## PARTS LIST — FIGURE J

| KEY NO. | PART NO.  | DESCRIPTION              | QTY. |
|---------|-----------|--------------------------|------|
| 1       | 997000221 | Battery Cover Spring     | 2    |
| 2       | 997956001 | Front Pocket             | 1    |
| 3       | 997955001 | Front Pocket Door        | 1    |
| 4       | 997941001 | Wheel Well (Right)       | 1    |
| 5       | 997940001 | Wheel Well (Left)        | 1    |
| 6       | 997937001 | Fender (Right)           | 1    |
| 7       | 997936001 | Fender (Left)            | 1    |
| 8       | 997935001 | Trim Panel (Right)       | 1    |
| 9       | 997934001 | Trim Panel (Left)        | 1    |
| 10      | 997939001 | Console (Right)          | 1    |
| 11      | 997938001 | Console (Left)           | 1    |
| 12      | 997000223 | 40V Battery Lid (Right)  | 1    |
| 13      | 997947001 | 40V Battery Lid (Left)   | 1    |
| 14      | 997967001 | Storage Lid              | 1    |
| 15      | 994000001 | Joystick Bellow Assembly | 1    |


| KEY NO. | PART NO.  | DESCRIPTION                 | QTY. |
|---------|-----------|-----------------------------|------|
| 16      | 997949001 | LCD Upper Cover             | 1    |
| 17      | 997948001 | LCD Lower Cover             | 1    |
| 18      | 997970001 | Charging Door               | 1    |
| 19      | 997954001 | Controller Cover            | 1    |
| 20      | 997000220 | Battery Cover Hinge Pin     | 2    |
| 21      | 997942001 | Rear Cover                  | 1    |
| 22      | 994989001 | Screw (M6 x 16 mm)          | 43   |
| 23      | 996297001 | Screw (M4 x 10 mm)          | 6    |
| 24      | 997094001 | Screw (M3 x 12 mm, Pan Hd.) | 12   |
| 25      | 994785001 | Clip-On Nut (M6)            | 16   |
| 26      | 997000194 | Charger Door Spring         | 1    |
| 27      | 997000195 | Charger Door Hinge          | 2    |
| 28      | 997076001 | Storage Bin Spring          | 1    |
| 29      | 997000214 | Storage Box Hinge Pin       | 3    |



PARTS LIST — FIGURE K

| KEY NO. | PART NO.  | DESCRIPTION                | QTY. |
|---------|-----------|----------------------------|------|
| 1       | 997922001 | Seat                       | 1    |
| 2       | 996046001 | Bolt (M8 x 25 mm, Hex Hd.) | 4    |
| 3       | 994770001 | Spring Washer (M8)         | 4    |

| KEY NO. | PART NO.  | DESCRIPTION                  | QTY. |
|---------|-----------|------------------------------|------|
| 4       | 994771001 | Washer (ID8.4 x OD16 x 1.6t) | 4    |
| 5       | 994891001 | Washer (M13)                 | 4    |






# RYRM8002CAN

## PARTS LIST — FIGURE L


| KEY NO. | PART NO.     | DESCRIPTION                      | QTY. |
|---------|--------------|----------------------------------|------|
| 1       | 140494001    | Charger, 120V-AC (1440W, 90V-DC) | 1    |
| 2       | 130662001DG9 | 80V Battery Pack (720Wh)         | 2    |
| 3       | 130531003DG9 | 40V Battery Pack (12Ah)          | 2    |
| 4       | 997000283    | Screw (M6 x 16 mm, Torx Hd.)     | 4    |
| 5       | 997000196    | Charging Port Mount              | 1    |
| 6       | 997971001    | 80V Charging Receptacle          | 1    |
| 7       | 997000213    | Mount Plate (Right)              | 1    |
| 8       | 997000210    | Battery Compartment Frame        | 1    |
| 9       | 994827001    | Washer (ID8.4 x OD24 x 2t)       | 4    |
| 10      | 994770001    | Lock Washer (M8)                 | 4    |
| 11      | 997000297    | Bolt (M8 x 90 mm, Hex Hd.)       | 4    |
| 12      | 997952001    | 40V Battery Bucket (Right)       | 1    |
| 13      | 997946001    | 40V Battery Bucket (Left)        | 1    |
| 14      | 997000292    | 80V Battery Bucket Assembly      | 1    |
| 15      | 994989001    | Screw (M6 x 16 mm, Torx Hd.)     | 11   |

| KEY NO. | PART NO.  | DESCRIPTION                | QTY. |
|---------|-----------|----------------------------|------|
| 16      | 997945001 | Push-To-Open Switch        | 1    |
| 17      | 997000211 | Battery Retainer           | 3    |
| 18      | 997000137 | Battery Retainer Spring    | 3    |
| 19      | 996294001 | Washer (ID4.3 x OD12 x 1t) | 3    |
| 20      | 996301001 | Lock Nut (M4)              | 3    |
| 21      | 997000198 | Battery Compartment Shock  | 2    |
| 22      | 997000139 | Cotter Pin                 | 4    |
| 23      | 997000138 | Damper Pin                 | 4    |
| 24      | 997000201 | Torsion Spring             | 1    |
| 25      | 997000199 | Compartment Lid Pin        | 1    |
| 26      | 997000200 | 80V Battery Lid            | 1    |
| 27      | 997000206 | Battery Cover Lock         | 1    |
| 28      | 997000299 | Lock Block Screw           | 2    |
| 29      | 996213001 | Screw (M5 x 16 mm)         | 8    |



**PARTS LIST — FIGURE M**

| KEY NO. | PART NO.  | DESCRIPTION                | QTY. |
|---------|-----------|----------------------------|------|
| 1       | 997000166 | Tow Plate                  | 1    |
| 2       | 997136001 | Bolt (M8 x 55 mm, Hex Hd.) | 1    |






# RYRM8002CAN

## PARTS LIST — FIGURE N

| KEY NO. | PART NO.  | DESCRIPTION                       | QTY. |
|---------|-----------|-----------------------------------|------|
| 1       | 997950001 | LCD Module Assembly               | 1    |
| 2       | 997000006 | LCD Buttons                       | 1    |
| 3       | 997958001 | Drive Deck Controller (Secondary) | 1    |
| 4       | 997957001 | Drive Deck Controller (Primary)   | 1    |
| 5       | 997959001 | Deck Controller (Primary)         | 1    |
| 6       | 997960001 | Deck Controller (Secondary)       | 1    |
| 7       | 281478009 | TIC Assembly                      | 1    |
| 8       | 997961001 | Controller Mounting Plate         | 1    |
| 9       | 997149001 | Beeper                            | 1    |
| 10      | 997094001 | Screw (M3 x 12 mm, Pan Hd.)       | 2    |
| 11      | 997098001 | Screw (M6 x 16 mm)                | 22   |
| 12      | 996058001 | Lock Washer (6 mm)                | 8    |
| 13      | 996281001 | Washer (ID 6.4 x OD 12 x 1.6t)    | 8    |
| 14      | 997855001 | 12 Volt Converter                 | 1    |
| 15      | 281496002 | Mixing Board Assembly             | 1    |


| KEY NO.           | PART NO.  | DESCRIPTION                   | QTY. |
|-------------------|-----------|-------------------------------|------|
| 16                | 997000080 | Terminal Box Assembly         | 1    |
| 17                | 997000192 | Main Relay (80V)              | 1    |
| 18                | 996565001 | Bolt (M5 x 16 mm, Hex Hd)     | 2    |
| 19                | 996286001 | Lock Washer (5 mm)            | 2    |
| 20                | 996295001 | Washer (ID 5.3 x OD 12 x 1t)  | 2    |
| 21                | 997000230 | Bolt (M6 x 25 mm, Socket Hd.) | 6    |
| 22                | 997962001 | Booster Mounting Plate        | 1    |
| 23                | 997976001 | 80V Booster                   | 4    |
| 24                | 997148001 | Screw (M6 x 20 mm)            | 16   |
| <b>Not Shown:</b> |           |                               |      |
|                   | 997000187 | Main Wiring Harness           | 1    |
|                   | 997000188 | Main Battery Cable            | 1    |
|                   | 997000189 | Battery Cable 2               | 1    |
|                   | 997000190 | Battery Cable 3               | 1    |
|                   | 997000191 | Battery Cable 4               | 1    |



**RYRM8002CAN****PARTS LIST — FIGURE O**

| KEY NO. | PART NO.  | DESCRIPTION                                       | QTY. |
|---------|-----------|---------------------------------------------------|------|
| 1       | 941110131 | Danger/Warning/Joystick Control/Brake Label (Eng) | 1    |
| 2       | 940851236 | Deck Warning Label (Eng/Fr)                       | 1    |
| 3       | 941110133 | Cutting Width Deck Label                          | 1    |
| 4       | 941705209 | 80V HP Brushless Hero Label                       | 1    |
| 5       | 941705211 | Sub Brand Logo Hero Label                         | 1    |
| 6       | 918012106 | 40V Battery Connection Instrucion Card            | 1    |
| 7       | 941194396 | QR Code                                           | 1    |
| 8       | 941110132 | Charging Port Label (Eng/Fr)                      | 1    |
| 9       | 941110130 | Data Label                                        | 1    |
| 10      | 940779513 | FCC Label                                         | 1    |

| KEY NO. | PART NO.  | DESCRIPTION                            | QTY. |
|---------|-----------|----------------------------------------|------|
| 11      | 918012106 | 80V Battery Connection Instrucion Card | 1    |
| 12      | 941110126 | Bagging Label (Eng/Fr)                 | 1    |
| 13      | 941705212 | Sub Brand Logo Non-Hero Label          | 1    |
| 14      | 941705210 | 80V HP Brushless Non-Hero Label        | 1    |
| 15      | 940851234 | Cut Finger CPSC (Eng/Fr)               | 1    |
| 16      | 941166362 | Deck Height Adjustment Label           | 1    |
| 17      | 941166348 | Discharge Chute Icons                  | 1    |
| 18      | 941234014 | Key Chain Tag (Eng/Fr)                 | 1    |
| 19      | 918012108 | Seat Assembly Tag                      | 1    |
| 20      | 918012104 | Joystick Hangtag                       | 1    |



| KEY | DESCRIPTION                      |
|-----|----------------------------------|
| A   | Brake Switch                     |
| B   | Headlights                       |
| C   | Charger Port                     |
| D   | Bagbooster Switch                |
| E   | Bagbooster Outlet                |
| F   | Switch w/Key                     |
| G   | Relay                            |
| H   | LCD Assembly                     |
| I   | 12 Volt Power Converter          |
| J   | Blade PTO                        |
| K   | Mixing Board Assembly            |
| L   | USB                              |
| M   | TIC Assembly                     |
| N   | Main Wiring Harness              |
| O   | Seat Switch                      |
| P   | 5 Amp Fuse                       |
| Q   | Beeper                           |
| R   | Neutral Switch Connector         |
| S   | Main Battery Cable 2             |
| T   | Primary Deck Motor Controller    |
| U   | Secondary Deck Motor Controller  |
| V   | Primary Drive Motor Controller   |
| W   | Secondary Drive Motor Controller |
| X   | Main Battery Cable 1             |
| Y   | Deck Motor                       |
| Z   | Drive Motor                      |

TO BATTERY CHARGING  
PORT, PAGE 24

TO TERMINAL BOX  
ASSEMBLY

TO MAIN WIRING  
HARNESS, PAGE 24

TO MAIN WIRING  
HARNESS, PAGE 24

TO TERMINAL BOX  
ASSEMBLY

| KEY | DESCRIPTION                                    |
|-----|------------------------------------------------|
| A   | 40 Volt Battery Harness (Main Battery Cable 3) |
| B   | 80 Volt Booster                                |
| C   | 40 Volt Battery Connector                      |
| D   | 80 Volt Battery Harness (Main Battery Cable 4) |
| E   | 80 Volt Battery Connector                      |
| F   | 40 Volt KTS Connector                          |
| G   | 80 Volt KTS Connector                          |
| H   | Terminal Box Assembly                          |
| I   | 100 AMP / 70 Volt Fuse                         |

